



FACSIA CUT OUT INSTRUCTIONS

1. Fold along the solid line to align the template with the facsia.
2. Cut along the dotted to make the template for the basin cut out.
3. Apply the template to the facsia and trace the basin cut out.
4. Using that trace line cut out the basin cut out from facsia.

FIXING INSTRUCTIONS

1. Apply generous amount of silicon sealant (not supplied) to the underside rim of the basin worktop
2. Fit the basin to the unit
3. Remove any excess sealant from the top rim of the basin worktop

