



## **ASPEN – SEMI COUNTERTOP VANITY UNIT**

**Please make aftercare instructions available to end-user**

### **Installation**

#### **Joining units**

If joining this unit to a back to wall WC base unit, it is recommended that units are joined together before fixing the unit to the wall.

#### **Fitting semi countertop basin**

To insert a semi countertop basin it will be necessary to cut both the worktop and the vanity unit fascia. It is much easier to do this before the worktop is fixed in position. It is assumed that the basin is supplied with a cutting template.

1. Position the worktop accurately on the base unit, but don't secure it.
2. Position the cutting template supplied with the basin and mark out the cut line on the worktop and fascia.
3. Remove worktop and cut – if using a jig saw on laminate worktops it is recommended that the top be cut with the finished side face down. To do this it will be necessary to mark the basin cut line on the underside of the worktop.
4. It is easier to cut the fascia by removing it from the unit - simply remove the screws on the back of the fascia.
5. **IMPORTANT NOTE:** Re-seal all cut edges using varnish or oil based paint - failure to re-seal the cut surfaces may result in water damage and will invalidate the product warranty.
6. Refit fascia and secure worktop into position (Note: with some semi countertop basins it is easier to fit the basin to the worktop before fitting the worktop to the base unit).
7. Fit washbasin according to manufacturers instructions. It is always easier to fit the basin waste and taps before securing the basin to the worktop. Make sure that any screws used to secure the washbasin are not too long - otherwise they may go right through the worktop. Always seal the mating surfaces between basin and worktops with silicone sealant. This prevents water seeping under the basin rim and damaging the worktop.
8. Connect plumbing services as necessary.

**CAUTION - IF ANY OF THIS UNIT IS CUT TO ALLOW FOR PIPE RUNS, IT IS ESSENTIAL THAT THE CUT SURFACES ARE RE-SEALED USING AN APPROPRIATE SEALANT. FAILURE TO RE-SEAL CUT SURFACES WILL INVALIDATE THE PRODUCT WARRANTY.**

#### **Product aftercare**

Cleaning: We recommend cleaning with a soft damp cloth and mild soap solution.

**DO NOT USE BLEACH OR CLEANERS CONTAINING BLEACH**

**DO NOT SCRUB OR SCOUR THE SURFACES**

**DO NOT ALLOW POOLS OF WATER TO REMAIN STANDING ON THE SURFACES**