

NO50AL NO65AL

NOOK RECESSIBLE CABINET

FIXING HOLE LOCATION TEMPLATE

1. Carefully cut out both templates along the dotted lines. Ensure after cutting that the templates are square and match the dimensions shown.

2. Noting the left and right designation, position the templates provided as shown below making sure the edges are flush against the inner edge of the carcass and the top face of the end cap.

3) Mark the hole position on each side of the cabinet at the corner of the template. Drill a hole large enough for the shank of the screw being used, (6mm for provided screw) but not large enough for the screw head to fit through.

Refer to product instructions for full installation details.

