

10 YEAR GUARANTEE

We have complete confidence in this Laura Ashley product and as such it is offered with a 10-year guarantee against defects in manufacture. The guarantee requires that this product be used in the manner for which it was intended and that it is installed and maintained in accordance with the fitting instructions and local water bylaws. The guarantee covers products in domestic use only. In the unlikely event that this product should fail during the guarantee period we will either replace the faulty part or the complete unit as appropriate.

Customer Services

Laura Ashley Bathrooms, Brassmill Lane Trading Estate, Bath BA1 3JF
Tel: 01225 303 900 | Fax: 01225 448 877

Email: info@lauraashleybathroomcollection.com Web: www.lauraashleybathroomcollection.com

Manufactured by Roper Rhodes under license for Laura Ashley Ltd.

REF: PL.LA13043. | 11.12 V1.00

LAURA ASHLEY HOME

MARLBOROUGH OAK 1000 UNIT

INSTALLATION & AFTERCARE INSTRUCTIONS



LA13043

RETAIN FOR FUTURE REFERENCE

MARLBOROUGH OAK 1000 UNIT

INSTALLATION & AFTERCARE INSTRUCTIONS

LAURA ASHLEY
HOME

INSTALLATION PROCEDURE

This unit has been carefully designed to work with other Laura Ashley products from this range. To prevent water ingress a silicone sealant should be applied between the top of the furniture and your chosen worktop (sold separately), but it is strongly recommended that you test the position of your worktop, basin and tap before applying the sealant (please refer to individual product instructions for installation information)

The worktop should be positioned so that the back face is flush with the back of the unit and there is equal worktop overhang at each side .

A number of adjustments can then be made to adjust the position of the drawers and doors to ensure smooth operation:

Drawer Adjustment

- 1) To adjust the height of the drawer front, fully extend the drawer then lift upwards to release from catches (A) and remove from the runners.
- 2) Turn the adjustable nut (B) of each drawer runner to adjust the drawer up (anti-clockwise) or down (clockwise).
- 3) Replace the drawer making sure that the catch (C) at the back of each drawer runner slots into the holes on the back of the drawer body. Once engaged, gently push the front of the drawer down onto the runners making sure the front catches (A) slot into the holes on the underside of the drawer body.

Door Adjustment

Up / Down adjustment: Loosen screws (A) to adjust the vertical position of door. Re-tighten screw once desired position is achieved.

Forward / Backward Adjustment: Loosen or tighten screw (B) to adjust door position in or out.

Left / Right Adjustment: Loosen screw (C) and adjust the door position left or right.

AFTERCARE INSTRUCTIONS

Whilst the item has a high quality durable finish, it should nevertheless be treated with care. Surfaces should be cleaned only using a soft damp cloth, clean water and non-abrasive cleaning products. They should be dried using a soft lint free cloth.

